

Operation Instruction For Use

Note: The laser can be operated only when the temperature of the laser housing comes back near to that of operating temperature (The most proper temperature is 15°C - 25°C). Otherwise, the laser maybe damaged because the large temperature differences.

1. Please don't put anything in front of or at the rear of the laser-head with 0.05m-0.1m area.

2. If putting the laser head and the power supply into a box, please make sure there are enough airways for the heat coming out.

3. If there is a fan in the box, please keep the fan flow and the heat flow of the laser in the same direction.

4. Above points should be done well, if not, the laser probably will be damaged by over heated.



1. Connect the laser head with the power supply correctly (Please note that the labels on the laser head and the power supply must be the same for ONE laser system. Unmatched connection will make the laser system fail.)

① ②

2. Check the position of the main power switch on the front panel of the power supply and make sure it is in the "OFF" – position. If not, press the switch side marked "o". ③

3. Check the key switch to see if it is in closing state. If not, please turn the key counter clockwise to vertical state. Then the key switch is in closing state. ④

4. Remove the protective label from the emission port of the laser head. If there is a shutter on the laser head, please open it. ⑤

5. Check the input voltage ⑧ indicated at the rear panel of the power supply, then connect the plug of power supply to the socket. ⑨

6. Switch on the power supply by pressing the main switch ③. Press the switch side marked "ON". Then the red LED will come on. ⑥

7. Open the key switch. Turn the key clockwise to the horizontal state ④. Then it is in working state, about 5 seconds, the green LED is lighted up. Turn the knob adjust the LD current to take right power of your need, then lock it. The laser works stably after about (Diode Laser 5 minutes), (DPSS Laser 15minutes). ⑦

8. Input TTL or Analog modulation, how to use please refer to "Notes of TTL or Analog modulation". ⑩

9. After using please close the key switch first ④, then close the master switch ③ and pull off the plug of power supply. ⑨

10. Put back protective label to the emission port of the laser head. If there is a shutter on the laser head, please close it. ⑤

CW / Modulation Toggle Switch: ⑪

@ CW: The Laser continuous output, cannot input Modulation

@ Modulation: If the laser by TTL modulation, the laser will continuous output without modulation signal, or you can input TTL modulation signal to control laser.

@ Modulation: If the laser by Analog modulation, the laser must input Analog signal (0-5VDC) to control laser power.

Emergency switch: ⑫

When unexpected accident occurs, you can press it down to switch off the laser. You need to reset the main power and key switch to restart the laser.

“Inter Lock”function of safety. ⑬

Pull out the crystal plug or disconnect the short wire on the plug (if there are two short wires, disconnect both of them), laser will stop working. At this point you must connect the plug or restore short wires, turn off the electronic lock, and then open it, the laser return to normal working station.

Knob: ⑭ The knob is fixed on the minimum current position as Main power factory default.

Turn the knob counter-clockwise, the output power is decreased, clockwise, the output power is increased.

LED Display: ⑮ Display the current as factory default, turn the knob change the current.

