


## Operation Instruction of Laser Pointer


### REPLACING THE BATTERIES

- Remove the laser pointer back tube
- Place one rechargeable battery.
- Insert batteries with the negative (-) side facing toward the spring



### OPERATING THE LASER POINTER

- Turn the key to red point, simply press the momentary push button to activate the laser pointer and release it to deactivate



### WARNING

Use of controls or adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.

### SAFETY PRECAUTIONS

- Do not use this product where the temperature exceeds 35°C or goes below 10°C.
- It is normal. The performance of the green laser pointer to be slightly affected by temperature.
- This product may malfunction if immersed in water or exposed to high levels of humidity.
- Dropping or impacting this product is not be used for a long period of time.
- For the high performance of the green laser the full of the rechargeable battery
- Keep this products away form children.
- The warranty will no longer exist once the product been taken apart.
- Warm up time under 5 minutes

### DISPOSAL OF BATTERIES

- Batteries must not belong to domestic waste.
- As a consumer you are obliged to give back all used batteries. You can hand in old batteries to the public assembly points in your municipality or everywhere you can buy batteries of the relevant sort.
- You will find the following symbols on harmful substances contenting batteries:



**RoHS**

